PI-321A-0101


User Manual






Packaging 01

Package Contents






Installation Instructions 02

Setting


Power-on


Plug the power cable into the camera, and then plug the power adapter into an outlet as shown in the figure below.



01/Install the Micro SD Card (Purchase)

- 1 Rotate the sphere upwards until you see the card slot.
- 2 Insert the Micro SD card (sold separately) into the card slot as shown in the figure below.






Installation Instructions 03

02/Install the Base

△ Make sure the ceiling is strong enough to withstand three times the weight of the camera.

- △ Avoid positioning the camera in an area that gets a lot of light shining directly into the camera lens.
- * The camera can be placed horizontally or mounted on the ceiling. Here we take ceiling mounting as an example.
- 1 Take out the drilling template and stick it to the chosen installation surface.
- 2 Drill holes according to the drilling template and insert three plastic anchors.
- 3 Use three screws to secure the base.



• Please tear up the drill template after installing the base if needed.

Installation Instructions 04

03/Install the Camera

Mount the camera to the base, and turn it clockwise until it is fixed.

